AWNING INSTRUCTIONS

To use your awning correctly:

1. Check and make sure the locking knobs on bottom rail are in the unlocked position

2. Using the crank handle wind the bottom rail to go down past the desired lock off point

NOTE: In windy conditions please be very cautious whilst lowering the awning as the wind will put pressure on the awning retention system and may even stop the awning from going down. If this situation occurs you will need to help your awning down by pushing against the mesh in the middle of the awning to relieve pressure off the sides.


- 3. Using your foot or hand slide the locks into place
- 4. Using your crank handle wind up to allow the awning mesh to go taut

To take awning back up to head box

- 1. Using your crank handle wind your awning for down slightly
- 2. Using your foot or hand slide the locking system back to unlock position
- 3. Using your crank handle wind your awning up into the head box

OSSIE O 11 Industrial Dr Coffs Harbour 66515499 0400237237 simon@ossieo.com.au







LOCKED

