

OSSIE O 11 Industrial Dr Coffs Harbour 66515499 0400237237 simon@ossieo.com.au

MOTORISED AWNING INSTRUCTIONS

To use your motorised awning correctly:

1. Check and make sure the locking knobs on bottom rail are in the unlocked position



2. Press the down button and allow the bottom rail to go down past the desired lock off point

NOTE: In windy conditions please be very cautious whilst lowering the awning as the wind will put pressure on the awning retention system and may even stop the awning from going down (but motor will still be working). If this situation occurs press stop button immediately and then you will need to help your awning down by pushing against the mesh in the middle of the awning to relieve pressure off the sides at the same time pressing the down button.


3. Using your foot or hand slide the locks into place



4. Press the up button to allow the awning mesh to go taut

To take awning back up to head box

- 1. Press the down button until it stops
- 2. Using your foot or hand slide the locking system back to unlock position



3. Press the up button and your awning will go up to the head box